

INSTRUCTIONS

1- Install Software

2- Connect interface to +12

3- Insert the USB on the PC

4- Windows folder ask for the drivers indicate:

c:\windows\sistem32

59F

pin 34 black

pin 17 Green

pin 16 Yellow

pin 4 Red

55F

K line Yellow

Negative Black

Red + 12v

Green +12v

